


Jacquard controller V2.0


Operation Manual

Regulations and operating environment:

- * Working temperature5-40 degree;
- * Relative humidity30-95% non condensation;
- * Power.....3 phase 380V \pm 10%, 49.5HZ-60.5HZ;
- * Earth.....good grounding, earthing resistance less than 10 ohms;
- * Water proof.....In accordance with IP54
- * While you repair or plug connector, you must shut off the power supply to operate.


(一) Main Windows:



1. Move the finger icon  to select a function by the key of “Up/Down /Left/Right” arrow;
2. Press the key of sure “√”, then go to the relative function;
3. Press the key of clear “×”, then clear the faults such as Data Parity, Oe time out etc.;

(二) File Utilities:



- * Press the key of “Up/Down” arrow to move “” icon to one function;
- * Press the key of “√” to select the function;
- * Press the key of “F4” to exit to Main Window.

(A) Read From USB Disk:

Transfer the design file from USB Disk to Flash Memory inside.

1. Insert a needed USB Disk, then list all design files in USB Disk;
2. If the Usb Disk is not ready, then press any key to exit to the prior window of File Utilities, display the window as follows:



3. If there is no file in Usb Disk, then press any key to exit to the prior window of File Utilities, display the window as follows:

```
Jacquard  controller  V2.0
-----Read USB-----

      EP File Not Found!
      Press any to Exit.
```

4. If there is no error, then list all design files as follows:


```
Jacquard  controller  V2.0
-----Read USB-----

      BY-139  . EP
      ⇨# JB-1   . EP
      BY230   . EP
      LZ316DZA. EP
```

- 1) Move the right arrow icon(⇨) to the selected design file by the key of “Up/Down” .
- 2) Press the key of F2 to select the design file, then display the symbol of “#” before the selected design file.
 - *Press the key of F2 in odd times, display the symbol of #.
 - *Press the key of F2 in even times, discard the symbol of #.
- 3) Press the key of √, If there is not a selected design file, return to the prior window of File Utilities.

4) If there exists a selected design file, then go on.


If the selected design file exists inside, display a window as follows:



* Press the key of sure(√), then continue to read design file.

* Press the key of clear(×), then return to the prior window.

5) If press the key of sure(√), continue to read the selected design file.



(B) Select a Design to Work:


Jacquard controller V2.0	
-----Select Design-----	
	WEA1x1-1. EP
	WEA1x1-2. EP
	ALLDOWN . EP
	ALLUP . EP
	BY-139 . EP
⇒ #	JB-1 . EP
	BY230 . EP
	LZ316DZA. EP

- 1) Move the right arrow icon(⇒) to the selected design file by the key of “Up/Down” .
- 2) Press the key of F2 to select the design file, then display the symbol of “#” before the selected design file to work.
 - *Press the key of F2 in odd times, display the symbol of #.
 - *Press the key of F2 in even times, discard the symbol of #.
- 3) If press the key of sure(√) , then go to next step.
 - If press the key of clear(×) or F4, return to the prior window.
- 4) If press the key of sure(√), select the deisng file to work(weave).Go to next step.

Jacquard controller V2.0	
-----Select Design-----	
JB-1. EP	
√ SURE	× CANCEL

- * Press the key of sure(√) , then go to next step.
- * Press the key of clear(×) , then cancel this operation, return to the prior window.

5) Transfer data of the design file to memory in interface control board.




(C) Del designs From Memory:

Delete a design from flash memory inside.

This operation is the same as that of “Select a design to work”.

(D) Erase all Flash Data:

This function will make data lost in the flash memory, so you must be carefully before you operate.



* Press the key of sure(√), then erase all flash data.

* Press the key of clear(×), then cancel this operation, return to the prior window.

(E) Write to USB Disk:

Select the design file inside to write to USB disk.

This operation is the same as that of “Select a design to work”.

(三) Job Status:

<p>Jacquard controller V2.0</p> <p>-----Job Status-----</p> <p>Design File:JB-1.EP</p> <p>Design Repeats...:980</p> <hr/> <p>⇒ Current Pick No.:59</p> <hr/> <p>Current Shift....:A shift</p> <p>Repeats Woven....:235</p> <hr/> <p>Device Status....:OK!</p> <p>Speed.....:1000 RPM</p>
--

- 1> Move the right arrow”⇒” to a job-item by the key of “Up/Down”.
- 2> When the key of sure(√) is pressed,there occurs a sparkling cursor.
Then, the key of Up/Down/clear(X) can make the parameter changed.
- 3> While there is a sparkling text cursor, the key of sure(√) is to
turn off the sparkling cursor.
If there is no sparkling cursor, the parameter cannot be changed.

(A) **Design file**:the current woven design file name.

(B) **Design Repeats**: the repeats of the current design file.

(C) **Current Pick No.**:

Under the condition of sparkling cursor:

- 1> The key of Up is to increase a pick.
- 2> The key of Down is to decrease a pick.
- 3> The key of Clear(X) is to reset the pick No. to 1.

(D) **Current shift**:

Under the condition of sparkling cursor:

- 1> The key of Up/Down is to select a current working shift among
A/B/C shift. The parameter of Repeats Woven is changed according
to the current shift.
- 2> The key of Clear(X) is to reset the Repeats Woven to 0.

(E) Repeats Woven: the output of current shift.

Under the condition of sparkling cursor:

The key of Clear(X) is to reset the Repeats Woven to 0.

(F) Device Status:

This indicates the device status.

If there exists a fault such as data-parity, Oe time-out etc, this item will display “FAULT”.

If there is no fault, this item will display “OK”.

(G) Speed..: This indicates the machine-weaving-speed in real time.

(四) Config:

Config

Hooks Number:2560-20x16x32
Ext. Name of File:EP
1st Hook Posi....:Left-Back
OE Time-Limited..:1200 secs
Hooks Move Dir...:Forward
Hooks Move Offset:0
Stop Roller Posi.:17
Dat Parity.....:Enable
Flat cables: 20column 1 1 1
 1 2 3 4 5 6 7 8 9 0 1 2
CT50 V V V V V V V V V V V V V
CT51 V V V V V V V V V X X X X

⇒ Permit:

Under the user's permit and machine-not-run, the operation is enable.

1> Move the right arrow"⇒" to an item by the key of Up/Down.

2> When the key of sure(√) is pressed,there occurs a sparkling cursor.

Then, the key of Up/Down can make the parameter changed.

3> While there is a sparkling text cursor, the key of sure(√) is to turn off the sparkling cursor.

If there is no sparkling cursor, the parameter cannot be changed.

4> Press the key of F4 to exit to main window and save the changed parameters after you have changed some config parameters.

(A) Hooks Number: Jacquard hook number and array.

To change this parameter according to electronic Jacquard real hook number.

Hooks Number: 2560-20x16x16

\\|/

Module array: 20 columns X 16 rows X 16 warp threads from front to back

Hooks Number: 2560-20x16x32

\\|/

Module array: 20 columns X 16 rows X 32 warp threads from front to back

(B) Ext. Name of File: (extend name of file)

- 1> This is used for Read-From-USB-Disk.
- 2> This includes the file formats such as EP、 JC5;
- 3> EP is for Bonas.
- 4> JC5 is for Staubli.

(C) 1st Hook Posi...: First(1st) hook position of Jacquard.

- 1> This decides on the position of the first warp thread.
- 2> If this parameter doesn't match the real position of warp thread,
It occurs that the weaving pattern is incorrect.
- 3> One of "Left-Back/Left-Front/Right-Back/Right-Front" is selected.
- 4> The direction of "Left-Back/Left-Front/Right-Back/Right-Front" is defined while the operator faces toward the weaving machine.

(D) OE Time-Limited...: 1200 secs

- 1> This is to protect the Module from too long time of onloading power and too high temperature.
- 2> Unit: second.

(E) Hooks Move Dir...:

- 1> This function of Hooks-Move-direction is to be compatible with the design file format of other factory.
- 2> This includes "Forward/Backward".

(F) Hooks Move Offset:

This makes the data of Jacquard design file move the offset according to Hooks-Move-Direction(Forward or backward).

(G) Stop Roller Posi.: Generally, In 17 hook position.

The user may change this parameter according to the design of CAD system.

(H) Dat Parity.....:

- 1> This includes "Enable/Disable";
- 2> The function of "Enable" checks whether there is a fault or not when interface CPU transfer the data;
- 3> The function of "Disable" does not check whether there is a fault or not when interface CPU transfer the data
- 4> If this selects "Enable", system will display the status of the flat-cable in device-status.

(I) Flat cables:

- 1> This can let user to choose some flat-cables to use.
- 2> The selected column number is equal to the Jacquard array(Hooks Number).


(J) Permit:


- 1> The user's operating password is "123678".
- 2> If the user wants to change some config parameters , you must input the correct password at first.

How to input the password ?

- 1> Move the right arrow"⇒" to Permit by the key of Up/Down.
- 2> Press the key of sure(√) ,there occurs a sparkling cursor.
Then, input the correct password(six keys).
- 3> Press the key of sure(√) to turn off the sparkling cursor.
Then you can change some config parameters.
- 4> During input-password, if you want to exit, press the key of clear(X).

(五) Test:



- 1> Move the right arrow" " to an item by the key of Up/Down.
- 2> When the key of sure(√) is pressed, there occurs a symbol of √ after the selected item.
- 3> The key of F3 is to start test-procedure in odd times.
The key of F3 is to stop test-procedure in even times.
- 4> During test-procedure, system displays "auto-test...".
- 5> Press the key of F4 to exit to main window.

(A) Transfer Data:

- *Simulate the machine-running-state to test the reliability of Driver-PCB and flat cables.
- *Press the key of F2 to display the number which is a counter for Jacquard data-transfer-not-reliable times.

(B) CLK&STB:

To make signals of CLK and STB sparkle every 1 second In Driver-PCB in order to check by user.

(C) Memory:

Test the memory in the interface CPU PCB at front of Jacquard.

(D) Heat Module:

In order to reduce the moisture of module before the machine starts.

(六) Status:

-----Status-----												
Communication.....:OK												
Flash(In Main PCB)...:OK												
Memory(Interface PCB):OK												
Time out of Module On:OK												

Running...												

Jacquard Data Parity.:OK												
Flat-cable:												
	1	2	3	4	5	6	7	8	9	10	11	12
CT50	V	V	V	V	V	V	V	V	V	V	V	V
CT51	V	V	V	V	V	V	V	V	V	V	V	V

- 1> Press the key of clear(X) to clear some faults such as data-parity and time-out-of-module-on etc.
- 2> Press the key of F4 to exit to main window.

(A) **Communication.....:**

* This indicates the status of communication between the Main CPU and the interface CPU at front of Jacquard.

* We use optical fiber to communicate in this system.

(B) **Flash(In Main PCB)...:**

(C) **Memory(Interface PCB)...:**

This indicates the status of memory in the interface CPU PCB at front of Jacquard.

(D) **Time out of Module On:**

When the machine stopped, If the time for magnetic modules power on is over OE Time-Limited, Time-out-of-Module-On will display fault and make magnetic modules power off.

(E) **Jacquard Data Parity.:**

This item indicates fault when system(Interface CPU Board at front of Jacquard) transfers the jacquard data incorrectly.

(F) **Flat-cable:**

This item indicates the 12 flat cables' status(connected to CT50/CT51/CT52/CT53).

Description of indicator lamps

一、Indicator lamps in control panel:

- 1) **Auto:**
It sparkles during auto-test.
- 2) **Fault:**
When this system occurs some faults, It sparkles.
- 3) **CPU OK:**
The sparkling lamp indicates that the Main-CPU starts to work.
Otherwise, the Main-CPU can not start.
- 4) **Start:**
It indicates the Weaving-machine-status(Run or stop).
- 5) **Dat1、 Dat2:**
They sparkle during the communication between the Main-CPU and Interface-CPU.

二、Indicator lamps in main-CPU board:

5VL、 3.3VL、 2.5VL:

They indicates whether there have the power supply of 5V、 3.3V、 2.5V or not.

三、Indicator lamps in interface-CPU board:

- 1) **5V、 3.3VL、 2.5VL:** They indicates whether there have the power supply of 5V、 3.3V、 2.5V or not.
- 2) **12V:** the supply of 12V for two sensors.
- 3) **V1、 V2:** sensor indicator lamps.
- 4) **OK1:**
While it sparkles, it indicates that IC24 is working. Otherwise,
It indicates that the IC24 does not work well.
- 5) **ANTI:**
While it sparkles, it indicates that the weaving-machine is reversing.
- 6) **COMOK:** not used.
- 7) **OK:** While it sparkles, it indicates that the chip of IC41 is working.
Otherwise, It indicates that the chip of IC41 does not work well.
- 8) **FAULT:** If the interfac-CPU detects some faults, it will sparkle.
- 9) **COM-OK:** If the communication between the Main-CPU and Interface-CPU is ok, it will sparkle.
- 10) **RES0:** It sparkles during auto-test procedure.

一、 Output signals:

1、 14、 2、 15、 3、 16、 4、 17-----》 1-8 color selectors
5、 18、 6、 19-----》 4 output (reserved);

1>IRF630 output, low level avail.

2>12 outputs by the control of proximity switch.

JP1 connect as follows:(JPx-JumPerx)

JP1: 1-2 short, not by the control of proximity switch.

2-3 short, by the control of proximity switch.

JP4 connect as follows:

If all eleven outputs are controlled by the proximity switch, Twelfth output may select the control method.

JP4: 1-2 short, Twelfth output is controlled by proximity switch.

2-3 short, Twelfth output is not controlled by proximity switch.

7-----》 stop roller (IRF630 output, low level avail);

8-----\ Relay output (NO);

20-----/

9-----\ +24V supply;

21-----/

10-----》 signal of proximity switch

22-----》 -24(GND);

**** JP2、 JP3 is to select the type of proximity switch;**

1-2 short, PNP type.

2-3 short, NPN type.

二、 Input signals:

1> Three group input signals (11、 23)、 (12、 24)、 (13、 25) .

2> 24V level;

3> Active signals:

* 11、 12、 13--Negative input;

* 23、 24、 25--Positive input;

* JP5、 JP6、 JP7: 3-4 short;

4> Passive signals:

* 11、 12、 13--Negative input;

* 23、 24、 25--Positive input;

* JP5、 JP6、 JP7: 2-3 short, 4-5 short;